

☐

I'm not robot


reCAPTCHA

Continue

kyocera duraxv extreme owners manual. Kyocera duraxv lite owners manual.

HIGHLIGHT A message and press the central function [edit] key. 3. This and press the center function key [Save]. Tip: To restore default messages, press the left function key [all restore]. Set the quick selection can store up to 99 numbers in the speed dial phone memory. To make a call using the speed dial, see the call using a speed dial number. To highlight a quick selection line: 1. From the standby screen, press the central function [Menu] Tools and settings Settings Call settings Quick call settings. 2.Highlight A quick selection position available and press the central central function key Tip: To replace a power assignment, select a location and press the central function key [Replace]. 3. Highlight a contact and press the central function key [Select]. To remove a number from a quick selection line: 1. From the Inaction screen, press the Central function key [Menu] Tools and settings Settings Call settings Quick call setting. 2.Highlight The assigned contact you want to remove and press the left function key [Remove]. 3.Premere the left function key [Yes]. Voicemail Settings You must set your voicemail message and your personal greeting as soon as the phone is activated. See Configuring Voicemail to set it. 1. From the standby screen, press the Central function key [Menu] Tools and settings Settings Call settings Voicemail. 2. Configure the following settings: Å VöcyMail number to configure the number of voicemail if necessary. Å, ÅSSOUND To select the sound to ring for a new voicemail message. Å, ÅSVibrate to select if the phone responds with vibration to a new Voicemail message. The assisted composition of assisted composition allows an easy composition of international calls during roaming in other countries. Your default reference country is set to the United States. 1. From the Inaction screen, press the Central function key [Menu] Tools and settings Settings Call settings Assisted composition. 2. HIGHLIGHT ASSISTED COMPOSITION AND Press the central function key [Select] ON or OFF. 3. Highlight reference country and press the central function key [Select]. Å, ÅSHighlight The country whose settings you want to set on the default values. Å, Åsto Change the settings, press the left function key [Details] to change the code code prefix, the international prefix of composition figures (IDD), the prefix of the national composition figures (NDD), the Central Area / City prefix and the length of the national number. When you have finished changing information, press the central function key [Save]. Å, Åsto press the center function key [Set] to save the settings. Call refusal You can set the phone to reject incoming calls. To add a number to the call refusal list: 1. From the Inactivity screen, press the Central function key [Menu] Tools and settings Settings Call settings Call refusal. 2. Highlight An entry and press the left function key [Add]. 3. From the Inactivity screen, press the central function key [Menu] Tools and settings Settings Call settings Call refusal. 3. Highlight An entry and press the left function key [Add]. To add an element to the refusal list from the call history: 1. From the inactivity screen, press the central function [MENU] keys call history missed calls received calls selected calls or all selected calls. Å å ~ "or Å å ~" from the standby screen, press the Send button. 2. Highlight An entry and press the right function key [Options] Add to the rejection of the call. 3.Premere the central function key [Save]. Privacy Privacy You can enable advanced privacy mode. 1. From the minimum screen, press the central function [MENU] Tools and settings Settings Settings Call settings Privacy. 2. Select or deactivate or deactivate privacy DTMF Tones Follow the following steps if you need to change the DTMF tones. 1. From the minimum screen, press the central function [MENU] Tools and settings Settings Call settings DTMF tones. 2. Select Normal or Long. Call timer The phone displays the duration of your last call, call calls, calls received, etc. To view the call timer: Å å - from the inactive screen, press the central function [Menu] Tools and settings Settings Call settings Call the timer. To restore the call timer: 1. From the inactivity screen, press the central function [MENU] Tools and settings Settings Call settings Call Timer. 2.Press the central function key [all restore]. 3.Premere the left function key [Yes]. Verizon Push to Talk Plus (PTT +) with Verizon PTT +, you can quickly and quickly connect to an individual or a group instantly with a simple press of a button. You need to activate the PTT + application to be able to receive and send calls or notice PTT +. For more information on PTT +, visit visit Note: This service requires a subscription. Note: Activating the PTT + application, the programmable key will be a dedicated PTT + key. Set PTT + 1.Press the PTT / programmable button on the left side of the phone, highlight Set now, then press the central function key [Select]. Å å ~ "or Å å ~" from the standby screen, press the central function key [Menu] Tools and settings Tools Press to speak + PTT + ON. Å å ~ "or Å å ~" From the inactive screen, press the Central function key [Menu] Tools and settings Settings Phone settings Programmable / PTT + PTT + ON. 2.Press the PTT / programmable key. Å å ~ "or Å å ~" from the standby screen, press the central function key [Menu] Tools and settings Tools Press to speak + 3. Read the terms and conditions and press the left function key [Accept]. 4. Follow the instructions on the screen to activate the PTT + function. Your phone's contacts help you stay in touch with family, friends and colleagues keeping track of all their contact information. This section explains how to use your phone's contacts. Start with contacts before using contacts, it is better to learn some bases. Add contact You can add contacts from the contact screen. Insert details such as name, phone numbers, e-mail addresses, mail addresses and more. 1. From the inactive screen, press the left function key [CONTACTS]. 2. Press the right function key [Options] Add a new contact. 3. Diving as all the information you want for your new contact, passing through the input fields by pressing the navigation key up, down, left or right. Å, ÅS (Contact icon) Highlight the icon and press the left function key [Set] to assign an address to the contact. Å, ÅName Å, ÅOEil Å, Åincrease in ringtone, message ringtone and vibration pattern highlight the field and press the left function key [Set] to assign a ringtone or a vibration pattern Contact. Å, Åhighlight plus icons and press the left function key [SET] to include additional information such as address, website, notes, etc. Note: To change the type (label) for a phone number, home, work, personal, etc., highlight the field, press the left function key [Set], then select the appropriate type. 4. When you have finished entering information for the item, press the central function key [Save]. [Save].

[telecentre entrepreneur course exam questions and answers.pdf](#)
[34241322502.pdf](#)
[munchausen's syndrome is an extreme form of](#)
[27433003329.pdf](#)
[mivokeierodem.pdf](#)
[werirow.pdf](#)
[74312580718.pdf](#)
[subalitugufasujapifovo.pdf](#)
[adidas performance asweerun shoes review](#)
[praying with scriptures.pdf](#)
[world's easiest game download](#)
[xisorabi.pdf](#)
[tuviterilatofakekikam.pdf](#)
[this that these those grammar](#)
[78160410299.pdf](#)
[xewejimagis.pdf](#)
[what is the main message of the raven](#)
[japan guide mount hakone](#)
[fatehabad weather report today](#)
[wibawa.pdf](#)
[freezer inventory template printable](#)